


Put the Track A through the other Track A Suspended.

Mount End cap and fasten the set screw.



Suspended set up to 1.5 m



User manual
Item nr: 11488008

RobLight


RobLight A/S, Nordhavnsvej 1A, DK-9900 Frederikshavn
T: +45 9244 4888, E: info@rob-light.com
www.rob-light.com

RobLight

Mounting



Lead the wire up through the Track support from the bottom until it reaches top and the square hole is not blocked.



Put the O-rings on the wire.






Set the wire lock on the wire and mount the electrical wire through the O-rings.



Mount the wire lock fitting on the ceiling and screw the wire lock into the fitting.

RobLight



Mount electrical wire through the End cap. Fasten the electrical wire in the Track and lock with set screws. Fasten the End cap with set screw and the relief of electrical wire with a screwdriver.