





# Changing of circuit board Wall - to - wall XPO-led

User manual








Mounting and installation of the following products.:


|           |           |         |
|-----------|-----------|---------|
| Item no.: | 1119 5430 | 3,000 K |
|           | 1119 5445 | 4,500 K |
|           | 1119 5530 | 3,000 K |
|           | 1119 5545 | 4,500 K |













Loosen the screws -  
do not remove them.

















RobLight accepts no responsibility for possible errors in printed and electronic material. RobLight reserves the right to alter or discontinue products without notice. © 2018 RobLight A/S.

# RobLight

|                       |                                                               |
|-----------------------|---------------------------------------------------------------|
| Roblon Lighting       | m: +45 9244 4888                                              |
| Nordhavnsvej 1A       | e: <a href="mailto:info@rob-light.com">info@rob-light.com</a> |
| DK-9900 Frederikshavn | w: <a href="http://www.rob-light.com">www.rob-light.com</a>   |